

SIMPO HV

Inverters Compatibility List

ZYC ENERGY
ZERO YOUR CARBON

Version: V1.3
Released Date: 2025-01-13



Inverters Compatibility List

Kostal

	HV6.4	HV9.6	HV12.8	HV16	HV19.2	HV22.4	HV25.6	HV28.8
PLENTICORE G3 S-4.0	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 S-5.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 S-7.0	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 M-8.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 M-10	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 M-12.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 L-15	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 L-17.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE G3 L-20	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 3.0	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 4.2	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 5.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 7.0	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 8.5	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE plus G2 10	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE BI G2 5.5/26	✓	✓	✓	✓	✓	✓	✓	--
PLENTICORE BI G2 10/26	✓	✓	✓	✓	✓	✓	✓	--

Note:

1. Inverter firmware version: For G3, SW 3.04.00.16312, or above; Plenticore G2 will be released in Oct.2024.
2. BMS firmware version: V1.5.0 or above.

Solis

	HV6.4	HV9.6	HV12.8	HV16	HV19.2	HV22.4	HV25.6	HV28.8
S6-EH3P(5~10)K2-H	✓	✓	✓	✓	✓	✓	✓	--
S6-EH3P(5~10)K-H-AU	✓	✓	✓	✓	✓	✓	✓	--
RHI-3P(5-10)K-HVES-5G	--	✓	✓	✓	✓	✓	✓	--
S6-EH3P(12~20)K2-H	✓	✓	✓	✓	✓	✓	✓	✓

Note:

1. Inverter firmware version: V0266 or above.
2. BMS firmware version: V1.5.0 or above.

GoodWe

	HV6.4	HV9.6	HV12.8	HV16	HV19.2	HV22.4	HV25.6	HV28.8
GW5K-ET	--	✓	✓	✓	✓	✓	✓	--
GW6.5K-ET	--	✓	✓	✓	✓	✓	✓	--
GW8K-ET	--	✓	✓	✓	✓	✓	✓	--
GW10K-ET	--	✓	✓	✓	✓	✓	✓	--
GW5KN-ET	--	✓	✓	✓	✓	✓	✓	--
GW6.5KN-ET	--	✓	✓	✓	✓	✓	✓	--
GW8KN-ET	--	✓	✓	✓	✓	✓	✓	--
GW10KN-ET	--	✓	✓	✓	✓	✓	✓	--
GW15K-ET	--	--	✓	✓	✓	✓	✓	✓
GW20K-ET	--	--	✓	✓	✓	✓	✓	✓
GW25K-ET	--	--	✓	✓	✓	✓	✓	✓
GW29.9K-ET	--	--	✓	✓	✓	✓	✓	✓
GW30K-ET	--	--	✓	✓	✓	✓	✓	✓
GW3600N-EH	✓	✓	✓	✓	✓	--	--	--
GW5000N-EH	✓	✓	✓	✓	✓	--	--	--
GW6000N-EH	✓	✓	✓	✓	✓	--	--	--
GW3600-EH	✓	✓	✓	✓	✓	--	--	--
GW5000-EH	✓	✓	✓	✓	✓	--	--	--
GW6000-EH	✓	✓	✓	✓	✓	--	--	--
GW3k-BH	✓	✓	✓	✓	✓	--	--	--
GW3600-BH	✓	✓	✓	✓	✓	--	--	--
GW5000-BH	✓	✓	✓	✓	✓	--	--	--
GW6000-BH	✓	✓	✓	✓	✓	--	--	--

Note:

1. Inverter ARM firmware version: For ET5-10,V27; For ET 15-30, V07; For ET G2; V02; For BH&EH, DSP12 , ARM28, or above.
2. BMS firmware version: V1.5.0 or above.

Solinteg

	HV6.4	HV9.6	HV12.8	HV16	HV19.2	HV22.4	HV25.6	HV28.8
MHS-3/3.6/4.2/5/6/8K-30	✓	✓	✓	✓	✓	--	--	--
MHT-4/5/6/8/10/12K-25	--	✓	✓	✓	✓	✓	✓	✓

Note:

1. BMS firmware version: V1.9.3 or above.

Contact Us



ZYC Energy Australia Pty Ltd



Suite 37 Ridge St North Sydney NSW 2060, Australia



+61 2 8006 1868



service@zyc-energy.com.au



ZYC Lithium Batteries S.L.



Calle Angelita Cavero 13 Oficina 4 Madrid (28027), Madrid, España



+34 6 9791 9475 / +49 71199871998



service@zyc.energy



ZYC Energy Company Limited



GuangKe Road 1, Pingshan, Shenzhen, P.R. China



+86 (0) 755-2839 4019



service@zyc.energy



WhatsApp: +86 19168831702



www.zyc.energy